



## Instruction Manual



## Room Clean

*Kills bacteria that causes odor.*

**CAUTION:** Read manual carefully for proper procedures and operation.

V040517

This product is designed to remove odors and contaminants from rooms using the power of ozone.

### HOW OZONE WORKS

Ozone, or O<sub>3</sub>, is a tri-atomic form of oxygen and is one of nature's most powerful oxidizers. O<sub>3</sub> has been used as a powerful organic cleaner for years. Ozone attacks and kills bacteria that cause odor and then converts safely back into oxygen, leaving your room scent-free.

In some people, minor levels of ozone exposure may cause irritation to the eyes or the respiratory system and may cause mild headache. If this occurs, move to fresh air and/or flush eyes gently with water to clear symptoms. Seek medical attention as needed if conditions persist.

### SPECIFICATIONS:

Model #	OLK-A03
Voltage	AC 110V to 240V, 50/60 Hz
Energy Consumption	4 watts
Size	130mm X 110mm X 90mm
Weight	300 g
Ozone Output	20-90mg/hr (adjustable)
Ambient Noise	26dB SPL to 34 dB SPL
Recommended Room Size	320 sqare feet

### FOR USE IN UNOCCUPIED ROOMS.

### OPERATION

1. Unpack the unit from its shipping carton and remove protective material from around the unit. Inspect the unit for any visible signs of physical damage. If damage is evident repack and contact the seller.
2. Plug the unit into a power socket. Rotate the control knob on the side of the unit to turn it on. For smaller rooms, a setting near the minimum should provide sufficient ozone to eliminate odors. For larger rooms up to 300 square feet, the maximum setting may be necessary to provide coverage to the entire room.
3. Once the unit has been turned on, the timer button on the face of the unit can be pressed to add additional time in 10 minute increments up to 30 minutes. Once the unit is activated and the timer set, leave the room. Allow an additional 10-30 minutes after the unit stops running before re-occupying the room.



**CAUTION:** To prevent electric shock, do not plug or unplug unit with wet hands. Do not disassemble or insert items into unit. Doing so may cause damage or electric shock.

### 2 YEAR LIMITED WARRANTY

Warranty is void if machine is mistreated or disassembled

Customer Service Line: 1-877-575-3173

[www.scentcrusher.com](http://www.scentcrusher.com)

## **MAINTENANCE**

- Periodically wipe the unit with a damp cloth. Do not use cleaning products or allow moisture into the unit.
- Keep the ozone outlet and air inlet free from lint. If necessary, use a vacuum cleaner on low power to remove any debris from the outlet or inlet.



Ozone Outlet



Air Inlet

## **LIMITED WARRANTY**

MoJack warrants the product for two years against failure due to defect in material or workmanship when product is used properly. MoJack will replace any defective part at no cost. This warranty does not cover any product that has been altered or adjusted, or any product that has been misused or abused. THIS IS THE CUSTOMER'S SOLE AND EXCLUSIVE REMEDY. MOJACK DISCLAIMS ALL IMPLIED WARRANTIES, INCLUDING THE WARRANTY OF MERCHANTABILITY AND FITNESS FOR A PARTICULAR PURPOSE. MOJACK SHALL NOT BE LIABLE FOR ANY INCIDENTAL OR CONSEQUENTIAL DAMAGES. SOME STATES OR PROVINCES DO NOT ALLOW THE EXCLUSION OR LIMITATION OF THE IMPLIED WARRANTIES OR THE REMEDIES FOR BREACH OF THE IMPLIED WARRANTIES, SO THESE EXCLUSIONS MAY NOT APPLY TO YOU. THIS LIMITED WARRANTY GIVES YOU SPECIFIC LEGAL RIGHTS, AND YOU MAY ALSO HAVE OTHER RIGHTS WHICH VARY FROM STATE TO STATE OR PROVINCE TO PROVINCE.

### **What does this warranty cover?**

This warranty covers against a failure due to a defect in material or workmanship within two years of original retail purchase.

### **What does this warranty NOT cover?**

This warranty does not cover any product which has been altered or adjusted in any way from its original model. It will not cover any product which has been damaged due to misuse, abuse, accident or negligence. This warranty does not cover incidental or consequential damages. This warranty does not apply to product purchased as used or from an unauthorized seller.

### **What will be done to correct problems?**

We will replace any defective part (within the coverage period) at no charge.

### **How do I contact someone about a warranty issue?**

You can contact our toll-free number 1-877-575-3173 or use our website at [www.scentcrusher.com](http://www.scentcrusher.com). In order to be eligible for this warranty you must keep your receipt as proof of date of sale.

### **What is the return policy?**

Please refer to the Return Policy and Procedures of your place of purchase for returns and refunds.

**NEED HELP?** Please contact our Customer Service Line BEFORE returning item to the store.

*Customer Service*

1-877-575-3173

[www.scentcrusher.com](http://www.scentcrusher.com)

**SCENT  
CRUSHER®**

A DIVISION OF  **MoJack.**

3535 N. Rock Road | Wichita, KS 67226 USA

1-877-575-3173

[www.scentcrusher.com](http://www.scentcrusher.com)